



BBQ 1012































GRILL WĘGLOWY

INSTRUKCJA MONTAŻU










Przeczytaj uważnie niniejszą instrukcję obsługi przed użyciem produktu.




1		2X	12		1X	
2		1X	13		4X	
3		1X	14		2X	
4		1X	15		2X	
5		1X	16		1X	
6		2X	17		2X	
7		1X	18		4X	
8		1X	19		2X	
9		3X	20		2X	
10		2X	21		1X	
11		1X	22		1X	
			A	M5x12	 	55X
			B	M5	 	55X
			C	M8	 	2X
			D	M4x10	 	2X





1




A	M5x12			24X
B	M5			24X
C	M8			2X







2




A	M5x12			21X
B	M5			21X





3




A	M5×12			6X
B	M5			6X
D	M4×10			2X

4



A	M5x12			4X
B	M5			4X

5




6

20

21

22



7

