

Instrukcja użytkowania BBQ0155


PRZED PRZYSTĄPIENIEM DO PRACY NALEŻY ZAPOZNAĆ SIĘ Z INSTRUKCJĄ!

ZACHOWAĆ SZCZEGÓLNA OSTROŻNOŚĆ!


Zasady bezpieczeństwa


- ✓ Urządzenie przeznaczone jest do indywidualnego użytku w ogrodzie.
- ✓ Grill nigdy nie może być użytkowany w pomieszczeniach zamkniętych!
- ✓ Grill należy ustawić na płaskim, poziomym, twardym, niepalnym i stabilnym podłożu zapewniającym wymaganą nośność, w miejscu osłoniętym od silnego wiatru.
- ✓ Zawsze należy ustawiać grill w bezpiecznej odległości od przedmiotów łatwopalnych np. gałęzi, drewnianych płotów lub podłóg, paliwa, podpałki itp.
- ✓ Nie ustawiać urządzenia pod wystającymi okapami, w pobliżu otwartych drzwi lub okien.
- ✓ Jako paliwa do grillowania używać wyłącznie węgla drzewnego lub brykietu z węgla drzewnego bez domieszek substancji wspomagających palenie.
- ✓ Nigdy nie używaj węgla kamiennego!
- ✓ UWAGA! Nie używać spirytusu ani benzyny do rozpalamia oraz ponownego rozpalamia po zgaśnięciu!
- ✓ Przy pierwszym użyciu grill powinien być rozgrzany a paliwo utrzymane w formie rozżarzonej przez co najmniej 30 minut zanim potrawy zostaną wyłożone na ruszt.
- ✓ Nie przyrządzać potraw zanim paliwo nie pokryje się warstwą popiołu!
- ✓ Grillowana żywność powinna być rozłożona równomiernie na całym ruszcie.
- ✓ Nigdy nie przemieszczać grilla, gdy jest już rozpalony - grozi poparzeniem lub pożarem!
- ✓ Nigdy nie pozostawiać rozpalonego grilla bez dozoru! Dzieci i zwierzęta muszą przebywać w bezpiecznej odległości od grilla! Grill mogą obsługiwać wyłącznie osoby trzeźwe!
- ✓ Należy zwrócić szczególną ostrożność na gorące lub ostre części grilla.
- ✓ Nie dotykać grilla nieosłoniętą dłonią. Podczas użytkowania używać rękawicy ochronnej i okularów ochronnych. Nie nachylać nigdy twarzy nad paleniskiem, chronić ubranie i włosy od kontaktu z ogniem.
- ✓ Nie dopuścić do nagromadzenia w komorze nadmiernych resztek żywności, tłuszczu bądź oleju, które mogą zapalić się podczas grillowania.
- ✓ Zachować szczególną uwagę podczas dokładania paliwa do palącego się grilla!
- ✓ Nie należy używać wody do gaszenia grilla! Rekomendowany jest piasek.
- ✓ Zawsze należy upewnić się, że grill jest całkowicie zimny, przed usunięciem popiołu lub zakończeniem pracy-usuwanie popiołu lub przenoszenie grilla, kiedy grill jest gorący grozi poparzeniem lub pożarem!
- ✓ Nie zamykać pokrywy na pierwszym etapie rozpalamia grilla.
- ✓ Nie używać wody do gaszenia płonącego tłuszczu!
- ✓ Nie dopuszczać do zbierania się węgla drzewnego bezpośrednio przy wewnętrznych ściankach grilla, gdyż prowadzi to do skrócenia żywotności urządzenia. Paliwo powinno być centralnie umieszczone wyłącznie na ruszcie węglowym.







- ✓ Dogaszony popiół i niedopalony węgiel drzewny składować z dala od łatwopalnych przedmiotów i konstrukcji.
- ✓ Przed przystąpieniem do złożenia grilla prosimy zapoznać się z niniejszą instrukcją w celu przeprowadzenia prawidłowego montażu.
- ✓ Przy użytkowaniu grilla zaleca się zabezpieczenie obecności sprzętu gaśniczego odpowiedniego typu.
- ✓ **Produkt nie jest zabawką i nie może być używany przez dzieci.**







Importer/producent zastrzega sobie prawo do dokonywania modyfikacji i zmian w instrukcji.





 ①	 ②	 ③
 ④	 ⑤	 ⑥
 ⑧	 ⑨	 ⑩
 ⑪	 ⑦	 ⑫
 ⑬	 ⑭	 ⑮
 ⑯	 ⑰	 ⑱

 ⑫	 ⑬	 ⑭	
 ⑮		 ⑯	 ⑰
 ⑱		A M6X12 X2 C M5X30 X4	B M5X45 X16 D M5X12 X11
E M4X30 X22 J M4 X2	F M4X8 X2 K M8 X2	G M5 X31 L 6-18 X4	H M4 X22

Instruction of use


BBQ0155

**PLEASE READ THE INSTRUCTIONS BEFORE
STARTING WORK!**


**EXERCISE PARTICULAR
CAUTION!**


Safety rules











- ✓ The device is intended for individual use in the garden.
- ✓ The grill must never be used indoors!
- ✓ Place the grill on a flat, level, hard, non-flammable, and stable surface that provides the required load-bearing capacity, in an area sheltered from strong wind.
- ✓ Always place the grill at a safe distance from flammable objects such as branches, wooden fences or floors, fuel, kindling, etc.
- ✓ Do not place the device under overhanging eaves, near open doors or windows.
- ✓ Use only charcoal or charcoal briquettes without additives for grilling.
- ✓ **WARNING!** Do not use alcohol or gasoline to ignite or re-ignite after the fire has gone out!
- ✓ At first use, the grill should be preheated and the fuel kept in the form of embers for at least 30 minutes before placing food on the grill.
- ✓ Do not cook food until the fuel is covered with a layer of ash!
- ✓ Grilled food should be evenly distributed over the entire grill.
- ✓ Never move the grill when it is lit to avoid burns or fire!
- ✓ Never leave a lit grill unattended! Keep children and pets at a safe distance! Only sober persons may operate the grill!
- ✓ Pay particular attention to hot or sharp parts of the grill.
- ✓ Do not touch the grill with an unprotected hand. Use protective gloves and goggles during use. Never lean your face over the fire pit; protect clothing and hair from contact with fire.
- ✓ Do not allow excessive food residues, fat, or oil to accumulate in the chamber as they can ignite during grilling.
- ✓ Be especially careful when adding fuel to a burning grill!
- ✓ Do not use water to extinguish the grill! Sand is recommended.
- ✓ Always ensure the grill is completely cold before removing ash or finishing work. Removing ash or moving the grill while hot can cause burns or fire!
- ✓ Do not close the lid during the initial stage of lighting the grill.
- ✓ Do not use water to extinguish burning fat!
- ✓ Do not allow charcoal to collect directly against the inner walls of the grill, as this shortens the device's lifespan. Fuel should be centrally placed only on the charcoal grate.
- ✓ Store extinguished ash and unburned charcoal away from flammable objects and structures. Before assembling the grill, please read this instruction for proper assembly. Never use bituminous coal!
- ✓ When using the grill, it is recommended to have appropriate fire extinguishing equipment on hand.
- ✓ **The product is not a toy and should not be used by children.**









**The importer/manufacture reserves the right to make
modifications and changes to the instructions.**





 ①	 ②	 ③
 ④	 ⑤	 ⑥
 ⑦	 ⑧	 ⑩
 ⑪	 ⑦	 ③
 ①	 ②	 ③
 ④	 ⑤	 ⑥
 ⑦	 ⑧	 ⑩
 ⑪	 ⑦	 ③

 ⑫	 ⑬	 ⑭	
 ⑮		 ⑯	 ⑰
 ⑱		A	M6X12
			X2
		C	M5X30
			X4
			X11
E	M4X30	F	M4X8
	X22		X2
J	M4	L	6-18
	X2		X4
	X2		
 ⑫	 ⑬	 ⑭	
 ⑮		 ⑯	 ⑰
 ⑱		A	M6X12
			X2
		C	M5X30
			X4
			X11
E	M4X30	F	M4X8
	X22		X2
J	M4	L	6-18
	X2		X4
	X2		